

System Components

The following equipment is connected to the AV system:


- 1x Flat panel displays (NEC)
- AV button controller
- Wireless Collaborator (Kramer Via)

AV button controller

The control is used for all interaction with the AV system

Show laptop on flat panel display

- Connect the laptop to the AV system by the provided HDMI cable
- Enable the laptop's dual display (Win/P/Duplicate or Mirror Display).
- Push the **Laptop** button on the AV control
- Ensure the laptop volume is turned up and not muted if the presentation contains an audio component (Youtube, DVD etc.) and adjust the volume by the **Volume** buttons on the AV control



Wireless Collaborator

Press the **PRESENT** button on the AV control and follow the on screen instructions for how to connect a BYOD (tablet/smartphone/laptop).

Support

AV Technical support Townsville:

Ext. 14643

AV Technical support Cairns:

Ext. 21700

Mediasite content:

mediasite@jcu.edu.au

Computers:

Ext. 15500

A/C or electrical faults:

Mex request

Security:

Ext. 16000