




Room concept

- The lecturer pushes media content to all the TV monitors in the room from the touch panel control at the lectern.
- Students collaborate at each work group table and connect a laptop to its associated wall mounted TV monitor. To enable this function, touch the **Student Display** button on the touch panel.
- Rooms 25-006 and 25-006 can for AV purposes be joined from the touch panel in 25-005 by touching the **Link Rooms** button.

Room layout



AV System:

- 4x large TV monitors
- Touch Panel for AV control
- AiO desktop PC
- Document camera
- Wireless presenter
- Microphone – wireless
- HDMI cable with adapters

Touch Panel

Used for all interaction with the AV system
Touch the panel to activate the system

Activate the AV System

- Touch the panel to activate the AV system



Desktop PC display

- Hold down the **Windows key** and press the **P-key** on the keyboard to access the PC display settings. Select 'Duplicate' on the floating menu. To show PowerPoint with notes, select 'Extend' from the floating menu.

Show Presentation

- **Show Desktop PC**
Touch the **Computer** button on the touch panel

- **Show Laptop**
 1. Connect the HDMI cable
 2. Enable the laptop's dual display (Duplicate/mirror)
 3. Touch the **Laptop** button on the touch panel

- **Show Document camera**
 1. Place the object or document on the tray
 2. Adjust the view using the controls on the device
 3. Touch the **Document Camera** button on the touch panel

- **Connect BYOD (laptop, tablet, smart phone) to the AV system**
 1. Touch the **Wireless Presenter** button
 2. Follow the instructions shown on the display system

Volume control

- Touch and slide the **Volume** button to adjust the playback volume of the PC or laptop. Ensure the PC/laptop volume is turned up and not muted.

Support

AV Technical support Townsville:	Ext. 14643
AV Technical support Cairns:	Ext. 21700
Computers:	Ext. 15500
A/C or electrical faults:	Mex request
Security:	Ext. 16000