



AV Equipment Guide

Room Concept

The lab seats 20 students at 5 tables each with a wall mounted flat panel display onto which the lecturer can push content (iMac, laptop, wireless presenter and document camera/visualiser).

System Components

The following equipment is connected to the AV system:

- 5x wall mounted flat panel displays
- iMac for lecturer and students
- Document camera/visualiser
- Wireless Presenter
- HDMI cable to connect digital laptop

Touch Panel

The touch panel is used for all interaction with the AV system



Log in to iMac

Use the JCU issued username and your password

Lecturer presentation

Show iMac

Press the **Computer button** on the touch panel to show the iMac on the 5 flat panels around the lab.

Show Laptop

Connect the HDMI, enable the laptop's dual display (Duplicate or mirror) and press the **Laptop button** to show it on the 5 flat panels around the lab.

Show Wireless Presenter

Touch the **Wireless Presenter button** to show the presenter on the 5 flat panels around the lab. Instructions for how to connect to the Wireless Presenter are shown on the panels.

Show Document Camera/Visualiser

Touch the **Document Camera button** to show the document camera on the 5 flat panels around the lab.

Volume control

Touch and slide the **Volume button** (located along the bottom of the touch panel) to adjust the volume of the audio content of an iMac or laptop presentation. Ensure the iMac audio and laptop volume is turned and not muted.

Support

AV Technical support Cairns:	Ext. 21700
AV Technical support Townsville:	Ext. 14643
Mediasite:	LTSE Staff
Computers:	Ext. 21777
A/C or electrical faults:	Mex request
Security:	Ext. 21293