




## Room concept

A presentation in A002-114 can be shown in room A002-116 by touching the **Room 114 Feed** button on the touch panel in A002-116.

## Room layout



## AV System

- 1x Large TV monitor
- Touch Panel for AV control
- AiO Desktop PC
- Document camera
- Wireless Presenter
- HDMI cable with adaptors

## Touch Panel

Used for all interaction with the AV system

## Activate the AV System

- Touch the touch panel to activate the AV system



## Desktop PC display

- Hold down the **Windows key** and press the **P-key** on the keyboard to access the PC display settings. Select 'Duplicate' on the floating menu. To show PowerPoint with notes, select 'Extend' from the floating menu.

## Show Presentation

- **Show Desktop PC**  
Touch the **Computer** button on the touch panel
  
- **Show Laptop**
  1. Connect the HDMI cable
  2. Enable the laptop's dual display (Duplicate/mirror)
  3. Touch the **Laptop** button on the touch panel
  
- **Show Document camera**
  1. Place the object or document on the tray
  2. Adjust the view using the controls on the device
  3. Touch the **Document Camera** button on the touch panel
  
- **Connect a BYOD (laptop, tablet, smart phone) to the AV system**
  1. Press the **Wireless Presenter** button
  2. Follow the instructions on the display system

## Volume control

- Touch and slide the **Volume** button to adjust the playback volume of the PC or laptop. Ensure the PC/laptop volume is turned up and not muted.

---

## Support

AV Technical support Cairns:	Ext. 21700
AV Technical support Townsville:	Ext. 14643
Computers:	Ext. 21777
A/C or electrical faults:	Mex request
Security:	Ext. 21293