



AV Equipment Guide

System Components

The following equipment is connected to the AV system:

- 1x Projector
- iMac
- VGA & 3.5mm audio cables – To connect Analog laptops

AMX 5-button keypad

The AMX 5-button keypad is used for all interaction with the AV system



Log in to iMac

Use the JCU issued username and password

Duplicate or Extend iMac display

Click on the Apple Icon / System preferences / Displays to change the display options of the iMac.

Projector and keypad button states

- If the **Off button** is lit on the keypad the system is in standby. Press the PC button to show the iMac on the projector screen. It will take a few minutes for the projector to warm up.
- If the **Off button** is flashing, the projector is going through a cool down phase. Please do not press any buttons while a button is flashing.
- To protect the projector bulb, the projectors are programmed to turn off after 3 hours continuous use. To reset the timer before the 3 hour limit, change the media input momentarily.

Local Presentation

Show iMac

Press the **PC button** on the keypad to show the iMac on the projector screen. We recommend using the VLC media player on the iMac to play DVDs.

Show Laptop

Connect the VGA and 3.5mm audio cables, enable the laptop's dual display (Duplicate) and press the **PC button** to show it on the projector screen. Please note the maximum resolution for this system is 1024x768 pixels.

Show Video

This is no longer an option in this room.

Volume control

Volume is controlled by pressing the **Up** or **Down button** on the keypad. Ensure the iMac and laptop volume is turned up and not muted if the presentation contains an audio component.

Support

AV Technical support Townsville:	Ext. 14643
AV Technical support Cairns:	Ext. 21700
Mediasite:	LTSE Staff
Computers:	Ext. 15500
A/C or electrical faults:	Mex request
Security:	Ext. 16000