



AV Equipment Guide


System Components

The following equipment is connected to the AV system:

- 2x Flat panel displays
- All-in-1 desktop PC with inbuilt camera and microphone for Mediasite Desktop Recordings
- Document camera/visualizer
- Videoconference codec
- Microphone
- HDMI, VGA, Mini Display Port, 3.5mm audio cables – Digital & Analog laptops

Tandberg Remote Control

The Tandberg Remote Control is used for all interaction with the AV system



Log in to desktop PC

Username: **avvisitor**

Password: **avvisitor**

Or use the JCU issued username and password

Duplicate desktop PC display

Hold down the Windows key and press the P-key on the keyboard to access the PC display settings. Select 'Duplicate' on the floating menu. To show PowerPoint with notes, select 'Extend' from the floating menu.

Local Presentation

Show Desktop PC

Briefly press the **Switch to PC** key on the Tandberg remote.

Show Laptop

Connect the appropriate cable and enable the laptop's dual display (Duplicate) and briefly press the **Switch to PC** key.

Show visualizer/document camera

Press & hold the **Switch to PC** key. A dropdown menu appears on the panel to the left. Select **Doc Cam** and press the **OK/Select** key (white tick).

Videoconferencing

Activate the AV system by picking up the Tandberg remote. If a menu appears in the bottom left corner, click the Arrow left key to close it.



Press the pan, tilt or zoom keys to adjust the camera settings. A picture-in-picture showing the current camera angle is shown at bottom right. Close the camera angle preview, by pressing the Exit button (the actions of the five function keys along the top of the remote, correspond to a soft key visible along the bottom of the flat panel).

Connect A Conference Call

Conference calls are scheduled by VAVS. To connect a conference manually, press the phone book key, navigate to the room/addressee in question and press the connect key (green handset).



The far end will appear on the left screen once the call is connected.

Videoconference Presentation

See the instruction for a local presentation, the presentation will appear on the right screen.



Support

AV Technical support Townsville:	Ext. 14643
AV Technical support Cairns:	Ext. 21700
Mediasite content:	LTSE Staff
Computers:	Ext. 15500
A/C or electrical faults:	Mex request
Security:	Ext. 16000