

## System Components

The following equipment is connected to the AV system:

- 1x Projector
- All-in-1 desktop PC with inbuilt camera and microphone for Mediasite Desktop Recordings
- DVD player
- VGA & 3.5mm audio cables – To connect Analog laptops

## Touch Panel

The touch panel is used for all interaction with the AV system



### Log in to desktop PC

Use the JCU issued username and your password

### Duplicate or Extend desktop PC display

Hold down the Windows key and press the P-key on the keyboard to access the PC display settings. Select 'Duplicate' on the floating menu. To show PowerPoint with notes, select 'Extend' from the floating menu.

## Projector

The projector will take a few minutes to warm up before an image appears on the projector screen after pushing one of the media buttons (PC, Laptop or DVD).

## Local Presentation

Presentations from this room can also be pushed to the Sim Lab, Master Chair or Microbiology at the Dentistry by touching the **Shared** button on the touch panel.

### Show Desktop PC

Press the **PC** button on the touch panel to show the desktop PC on the projector screen. We recommend using the VLC media player on the desktop PC to play downloaded material.

### Show Laptop

Connect the VGA and 3.5mm audio cables, enable the laptop's dual display (Duplicate) and press the **Laptop** button to show it on the projector screen. Please note the maximum resolution is 1024X768 pixels for this system.

### Show DVD

Turn on the DVD player and insert the DVD. Press the **DVD** button on the touch panel and Press the **Play** button on the player to show the DVD on the projector screen

### Volume Control

Touch the Volume button on the touch panel to make adjustments to the volume of the PC, Laptop and DVD. Ensure the desktop PC and laptop volume is turned up and not muted if the presentation contains an audio component.

---

## Support

AV Technical support Cairns:	Ext. 21700
AV Technical support Townsville:	Ext. 14643
Mediasite content:	mediasite@jcu.edu.au
Computers:	Ext. 21777
A/C or electrical faults:	Mex
Security:	Ext. 21293